












Accessoires pour les maisons Smoby

Vérifier la compatibilité :



	810912	810903	810905	810901	810902	810909	810904	810907	810910	810911
 810712	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/> *			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> 1 Set		
 810710	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/> *			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> 1 Set		
 810713	<input checked="" type="checkbox"/>			<input type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> 2 Sets		
 810711	<input checked="" type="checkbox"/>			<input type="checkbox"/>			<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> 2 Sets		
 810800	<input checked="" type="checkbox"/>							<input checked="" type="checkbox"/> 2 Sets		
 810500	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> 2 Sets	<input checked="" type="checkbox"/>	
 810406	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> 2 Sets	<input checked="" type="checkbox"/>	
 810403	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> 2 Sets	<input checked="" type="checkbox"/>	
 810405	<input checked="" type="checkbox"/>		<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> 2 Sets	<input checked="" type="checkbox"/>	
 810203	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/> 3 Sets	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
 810202	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> 3 Sets	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>

Adoptable sur toutes les tables pique-nique Smoby.

* à vérifier : possible seulement s'il y a des trous (pré-perçages) sur la façade, pour fixer la cuisine.